

IX.6.3-SYSTEM-EOUTPT COMMON BLOCK EOUTPT

Purpose

Common Block EOUTPT contains output indicators used by Function ESP.

Listing

```
COMMON /EOUTPT/ IWS,IFPLT,NCALL
```

Description of Variables

<u>Variable</u>	<u>Type</u>	<u>Dimension</u>	<u>Word Position</u>	<u>Description</u>
IWS	I*4	1	1	Water supply units indicator: 0 = regular units 1 = water supply units
IFPLT	I*4	1	2	Frequency plot indicator: 0 = no plot 1 = plot
NCALL	I*4	1	3	Number of calls to the end of run summary table subroutine